


CICADA & MICROGATE REI2

Connection Manual

1. Connecting the software.

Setup the serial port of MicroGate REI2



2. The following variables was supported

| Name | Description |
|--------------------------------|-------------------------------------|
| <i>Player:Time</i> | Match time of current player |
| <i>Player:JumpingPenalties</i> | Jumping penalties of current player |
| <i>Player:TimePenalties</i> | Time penalties of current player |
| <i>Player:TotalPenalties</i> | Total penalties of current player |
| <i>Player:Rank</i> | Rank of current player |